



- NOTES:
1. AREAS OF PATCHING AND POTHOLE REPAIR TO BE DETERMINED IN THE FIELD WITH THE ENGINEER OR REPRESENTATIVE PRESENT PRIOR TO REPAIR.
  2. REMOVE THE SURFACING AND BASE MATERIAL TO THE DEPTH AT WHICH BASE FAILURE OCCURRED.
  3. THE CUT AROUND THE FAILED AREAS SHOULD BE RECTANGULAR WITH FACES STRAIGHT AND VERTICAL AND SHOULD EXTEND AT LEAST 12" INTO GOOD PAVEMENT OUTSIDE THE FAILED AREA.
  4. TACK COAT THE PREPARED EDGES OF THE SURFACE SURROUNDING THE AREA BEING REPAIRED TO ENSURE A BOND BETWEEN THEM AND THE PATCH MATERIAL.


