



FOUNDATION PLAN
SCALE: 1/16" = 1'-0"

- NOTE:**
1. REMOVE TOP SOIL, ROOTS, ETC. SEAT ALL FOOTINGS IN UNDISTURBED SOIL, OR FILL MATERIAL COMPACTED TO 95%.
 2. COMPACT FILL MATERIAL TO 95% COMPACTION. TEST TO ASSURE RESULTS.
 3. TREAT SOIL BELOW SLAB FOR TERMITES.
 4. CONCRETE MIX SHALL BE 3000 PSI.
 5. CONCRETE TESTING TO REQUIRE 3 TEST CYLINDERS FOR EACH BAYS POUR.

