



NOTE:

1. Pressure Test All Suction Lines Upon Installation @ 10-15 PSI max.
2. Keep pressure on Suction Lines for the entire DURATION of construction.
3. Pressure should NOT drop more than 2 PSI.
4. Watch for problems when excavating driveways.
5. Placement of suction lines is critical.
6. Do NOT put screens on the suction lines

**CAR WASH RECLAIM SYSTEM
STANDARD RECLAIM 3 TANK**
(SEE RECLAIM SHEET FOR DETAIL)

NOTE:

1. ALL UNDERGROUND TANKS AND PIPING BY CONTRACTOR
2. PIPE LOCATIONS SHOULD BE USED FOR ANY TANK
3. ALL INTERNAL TANK PLUMBING TO BE 6\"/>

NOTE:
FIELD VERIFY ALL PLUMBING REQUIREMENTS WITH CARWASH MFG.

#	DESCRIPTION	DATE
A	ADDED RESTROOMS	07-19-13

RAINFOREST CARWASH

5026 HARDY ST.
HATTIESBURG, MISSISSIPPI

JOB No:	2176	DATE:	06-28-2013
DRAWN BY:	JCT	CHECKED BY:	CD

CHIEF ENGINEER, EMMETT DAMMON, P.E.
554 OLD SPANISH TRAIL
SLIDELL, LA 70458

dammonengneering.com
dammoneng@bellsouth.net
PHONE: 985-649-5832
FAX: 985-641-5950