



COLUMN DETAIL

N.T.S.

NOTE:

1. SEAT ALL FOOTINGS IN UNDISTURBED SOIL.
2. INSTALL EXPANSION JOINTS EACH 10' IN PORCH.
3. DRIVING SURFACE IN PORCH SHALL BE 6" THICK CONCRETE, WITH 6x12/01 REINFORCING 3000 PSI.