

DIRECTORY	CURT. NO.	BR. AMPS	DIRECTORY	CURT. NO.	BR. AMPS
EM LTS	1	20	2	2	20
EXTERIOR LTS	3	20	4	4	20
LTS	5	20	6	6	20
LTS	7	20	8	8	20
LTS	9	20	10	10	20
REFRIDGERATOR	11	20	12	12	20
KITCHEN REC	13	20	14	14	20
KITCHEN REC	15	20	16	16	20
REC	17	20	18	18	20
REC	19	20	20	20	20
REC	21	20	22	22	20
REC	23	20	24	24	20
REC	25	20	26	26	20
SPACE	27	20	28	28	20
SPACE	29	20	30	30	20

VOLTAGE: 120/208V 1 PHASE 3 WIRE 5N
MAIN BREAKER: 200A, MCB
MOUNTING: SURFACE
NOTE: FEED THROUGH WUGS

DIRECTORY	CURT. NO.	BR. AMPS	DIRECTORY	CURT. NO.	BR. AMPS
2	2	20	4	4	20
4	4	20	6	6	20
6	6	20	8	8	20
8	8	20	10	10	20
10	10	20	12	12	20
12	12	20	14	14	20
14	14	20	16	16	20
16	16	20	18	18	20
18	18	20	20	20	20
20	20	20	22	22	20
22	22	20	24	24	20
24	24	20	26	26	20
26	26	20	28	28	20
28	28	20	30	30	20

VOLTAGE: 120/208V 1 PHASE 3 WIRE 5N
MAIN BREAKER: 200A, MLO
MOUNTING: FLUSH
NOTE:

DIRECTORY	CURT. NO.	BR. AMPS	DIRECTORY	CURT. NO.	BR. AMPS
100	100	30	2	2	20
101	101	30	4	4	20
102	102	30	6	6	20
103	103	30	8	8	20
104	104	30	10	10	20
105	105	30	12	12	20
106	106	30	14	14	20
107	107	30	16	16	20
108	108	30	18	18	20
109	109	30	20	20	20
110	110	30	22	22	20
111	111	30	24	24	20
112	112	30	26	26	20
113	113	30	28	28	20
114	114	30	30	30	20

VOLTAGE: 120/208V 3 PHASE 4 WIRE 5N
MAIN BREAKER: 200A, MCB
MOUNTING: SURFACE
NOTE:

DIRECTORY	CURT. NO.	BR. AMPS	DIRECTORY	CURT. NO.	BR. AMPS
100	100	30	2	2	20
101	101	30	4	4	20
102	102	30	6	6	20
103	103	30	8	8	20
104	104	30	10	10	20
105	105	30	12	12	20
106	106	30	14	14	20
107	107	30	16	16	20
108	108	30	18	18	20
109	109	30	20	20	20
110	110	30	22	22	20
111	111	30	24	24	20
112	112	30	26	26	20
113	113	30	28	28	20
114	114	30	30	30	20

VOLTAGE: 120/208V 3 PHASE 4 WIRE 5N
MAIN BREAKER: 200A, MCB
MOUNTING: SURFACE
NOTE:

6 PANEL SCHEDULES

SCALE: NTS

