


# KOHLER<sup>®</sup> SERVICE PARTS

TRITON™ KITCHEN SINK FAUCET WITH SPRAY  
K-7827-\*\*-\*\*-AA, K-7832-\*\*-\*\*-AA



## SERVICE PARTS

ITEM NO.	PART NO.	DESCRIPTION
1	58039	Spout Assembly (9-1/2")
2	38824	Spout Assembly (8")
3	41056	Aerator
	41781	Aerator - 1.5 GPM
4	29464	O-Ring, 118
5	41495	Lower Bushing
6	52393	Diverter Assembly
7	32751	Nut, .5-14 NPSM
8	40080	Nut, .5-14 NPSM
9	34274	Washer, 29/32 x 1 5/16
10	50538	Valve Body, Kitchen
11	41045	Guide, Spray
12	33326	Nut, 1-20 UNEF-2B
13	34564	Spray & Hose Assembly
14	30430	Ceramic Valve (Clockwise Close)
	30431	Ceramic Valve (Counterclockwise Close)
15	59027	Spline Adapter
	42685	Spline Adapter (for Wristblade)
16	52645	Deck Kitchen/Bonnet Assembly (Standard Handle)

ITEM NO.	PART NO.	DESCRIPTION
17	53187	Wristblade Handle Assembly
18	52636	Lever Handle, Small Bonnet Assembly
19	52639	4-Prong Handle & Bonnet Assembly
20	56074	Screw, .164-32 UNC x .31
21	52623-C	Button Cap, Blue
	52623-H	Button Cap, Red
22	52622	Button Cap
23	58891-S	Screw, 8-32 x .51
24	31490	Screw, .164-32 UNC-2A x .50
25	58892-S	Screw, 8-32 x .67

## SERVICE KITS

PART NO.	ITEM NO.	QTY.	DESCRIPTION
38847	7	2 ea.	Nut, .5-14 NPSM
	8	2 ea.	Nut, .5-14 NPSM
	9	2 ea.	Washer, 29/32 x 1 5/16
34329			Spray Guide Assembly,
	11	1 ea.	Guide, Spray
	12	1 ea.	Nut, 1-20 UNEF-2B

Variation and/or finish/color code may be required when ordering.