





K#	Pump	Pump Switch	Bracket	w/Heater	Control Retrofit Kit
1330-**-AA	60937	30775	67793	N/A	500460
1330-**-AB	60910	30775	90986	N/A	500460
1330-H**-AA	60937	30774	67793	External	500460
1330-H**-AB	60910	30774	90986	External	500460
1330-N**-AA	73572	73589	N/A	In Pump	94260
1330-H1**-AA	93829	73589	N/A	In Pump	N/A




****Finish/color code must be specified when ordering.**




****Finish/color code must be specified when ordering.**


500460
Control Assy




94260-AA
Control Assy




Auxiliary Control Diagram



****Finish/color code must be specified when ordering.**







Suction Assy for Pump 60910



Heater Assy

****Finish/color code must be specified when ordering.**



****Finish/color code must be specified when ordering.**

SERVICE PARTS

ITEM	PART NO.	DESCRIPTION
1	61972	Tube
2	65157	Finger Nut
3	65156**	Flange (AA/AB, H-AA/AB Model)
	73513	Flange (N/H1 Model)
4	67429	Jet Flange
5	K-9695**	Trim Kit
6	65036	Flange
7	65355	Spacer
8	67999**	Cover
9	65054	Screw
10	65226**	Plug
11	91017	Check Valve
12		Available in Service Kit Only
13	67665	Plug
14	67889	Housing
15	94821	O-Ring
16	60848	Connector (AA/AB Model)
	60845	Connector (H-AA/AB Model)
	93709	Connector (N/H1-AA Model)
17	60979	Slip Nut (AA/AB Model)
	60979-A	Slip Nut (N/H1-AA Model)
18	60797	Tee
19		Available in Service Kit Only
20		Available in Service Kit Only
21	66265	Coupling (AA/AB Model)
	61249	Coupling (N/H1-AA Model)
22	65056	Elbow (AA/AB, H-AA/AB Model)
	93685	Elbow (N/H1-AA Model)
23	65885	Gasket
24	65036	Flange
25	65069	Tube
26	65122	Elbow
27	61072	Tube
28	90986	Pump Bracket
29	91150	Bolt
30	67111	Washer
31	67095	Washer
32	60125	Washer
33	64163	Screw
34	60043	Washer
35	60044	Nut
36	67124	Nut
37	67123	Washer
38	63068	Motor Support Bracket
39	65791	Washer
40	68686	Cord
41	68705	Switch
42	65198	Circuit Board Assy
43	60340	Cover
44	65186	Knob, Thermostat
45	60540	Thermostat
46	65194	Heater Flange
47	69079	Screw
48	63563	Screw
49	60320	Screw
50	64468	Washer
51	67264	Strain Relief Bushing
52	64463	Washer
53	65196	Heater Tube
54	65197	O-Ring
55	90153	Nut
56	93841	Screw
57	61563	Tee
58	93538	Neck Switch
59	63267	Tube
60	90154	Locknut
61	65886	Gasket
62	60559	Elbow
	61213	Elbow
63	73518	Plug
64	65331	Band Seal
65	60561	Reducer
66	60979	Slip Nut
67	60848	Connector
68	69589	Bushing

SERVICE PARTS

ITEM	PART NO.	DESCRIPTION
69	66537	Circuit Board
70	91239	Air Switch
71	67065	Lug
72	91355	Washer
73	65160	Enclosure
74	65193	Support
75	62959	Screw
76	64212	Washer
77	65328	Strap
78	65329	Bracket, Strap
79	68693	Cord Grip
80	67264	Cord Grip
81	30774	Switch (H-AA/AB Model)
	30775	Switch (AA/AB Model)
82	500405	Decal (H-AA/AB Model)
	500406	Decal (AA/AB Model)
83	73589	Switch, Assy (N/H1-AA Model)
84	73521	Switch, Wire
85	93765**	Switch, Cover
86	61536	Elbow
87	65574	Heater Strap (AA Model)
	90608	Heater Strap (BA Model)
88	92076	Adapter
89	60797	Tee
90	94318-B	Hose
91	93511**	Cover
92	93493	Sensor
93	93931	Screw
94	93509	Neck Jet Body
95	93542	Neck Jet Gasket
96	93823	Nut
97	93848	Elbow
98	93948-D	Hose
99	93948-A	Hose
100	94256	Elbow
101	94495	Pillow, Neck
102	94726-A	Pillow Cover, White
	94726-B	Pillow Cover, Black
103	94268	Screw
104	94268	Bushing
105	94274	Adapter
106	50506	Screw
107	94095	Body
108	94093	Butterfly
109	94094	Seal
110	94273	Motor
111	63149	Screw
112	67109	Bolt
113	60985	Shaft Seal
114	73558	O-Ring
115	73559	Nut
116	21998	Screw
117	74705	Barrier
118	73569	Base
119	94812	Screw
120	73573	Motor
121	94287	Bushing
122	94285	Interconnect Cord
123	73577	Impeller
124	73575	Cover
125	73580	Circuit Board Assy
126	93820	Capacitor
127	94062	Spacer
128	74824	Bolt
129	60911	Motor
130	60974	Motor
131	60994	Impeller
132	60993	Impeller
133	60972	Slinger
134	60927	Volute Assy
135	74823	End Cap
136	60912	Shim Kit
137	60981	O-Ring

**Finish/color code must be specified when ordering.

SERVICE PARTS

ITEM	PART NO.	DESCRIPTION
138	60926	Cover
139	60982	Screw
140	62726	Screw
141	73515-A	Isolation Mount
142	94408	Cover
143	94415	Circuit Board
144	94416	Insulation
145	94450	Wire
146	61776	Washer
147	94407	Box
148	73598	Screw
149	73594	Motor Assy
150	73596	Seal
151	73593	Body
152	73597	Plate
153	93411	Bracket
154	97146	Screw
155	93325	Cannister
156	93326	Rotor
157	97143	O-Ring
158	91930	Shaft Assy
159	92024	Spacer
160	94403	Motor
161	97145	Screw
162	69137	Coupling
163	61361	Elbow
164	60557	Elbow
165		Available in Service Kit Only
166	94269	Mounting Plate
167	91820	Sleeve
168	91819	Gommet
169	94405	Screw
170	95045	Screw
171	94307	Connector

SERVICE KITS

PART NO.	ITEM	QTY.	DESCRIPTION
93838			1" Tube Kit
	12	1 ea.	Tube
		2 ea.	Coupling
94889			1 1/4" Suction Tube Kit (AA/AB Model)
	19	1 ea.	Tube
		1 ea.	Elbow
94890			1 1/2" Suction Tube Kit (N-AA/H1-AA Model)
	19	1 ea.	Tube
		1 ea.	Elbow
93839			1 1/4" Tube Kit (AA/AB Model)
	20	1 ea.	Tube
		2 ea.	Coupling
94853			1 1/2" Tube Kit (N-AA/H1-AA Model)
	20	1 ea.	Tube
		2 ea.	Coupling
65182			Whirlpool Heater Assy
	40	1 ea.	Cord
	41	1 ea.	Switch
	42	1 ea.	Circuit Board Assy
	43	1 ea.	Cover
	44	1 ea.	Knob
	45	1 ea.	Thermostat
	46	1 ea.	Heater Flange
	47	2 ea.	Screw
	48	1 ea.	Screw
	49	1 ea.	Screw
	50	1 ea.	Washer
	51	1 ea.	Strain Relief Bushing
	52	1 ea.	Washer

SERVICE KITS

PART NO.	ITEM	QTY.	DESCRIPTION
500460			Control Assy
	49	6 ea.	Screw
	68	1 ea.	Bushing
	69	1 ea.	Circuit Boar Assy
	70	1 ea.	Air Pressure Switch
	71	3 ea.	Lug
	72	1 ea.	Washer
	73	1 ea.	Enclosure Assy
	74	2 ea.	Support
	75	1 ea.	Screw
	76	1 ea.	Washer
	77	1 ea.	Strap
	78	1 ea.	Bracket, Strap
94260			Auxiliary Control
	49	3 ea.	Screw
	142	1 ea.	Cover
	143	1 ea.	Circuit Board Assy
	144	1 ea.	Insulation
	145	1 ea.	Wire
	146	1 ea.	Washer
	147	1 ea.	Box
94275			B-Fly Assy
	66	1 ea.	Slip Nut
	67	1 ea.	Connector
	104	1 ea.	Bushing
	105	1 ea.	Adapter
	106	8 ea.	Screw
	107	2 ea.	Body
	108	1 ea.	Butterfly
	109	1 ea.	Seal
	110	1 ea.	Motor Assy
	111	1 ea.	Screw
73592			Valve Assy
	66	1 ea.	Slip Nut
	67	1 ea.	Connector
	148	2 ea.	Screw
	149	1 ea.	Motor
	150	1 ea.	Seal
	151	1 ea.	Body
	152	1 ea.	Plate
93590			Neck Jet Manifold
	92	1 ea.	Sensor
	93	1 ea.	Screw
	94	1 ea.	Neck Jet Body
73572			Pump (w/ Integral Heater)
	113	1 ea.	Seal
	114	1 ea.	O-Ring
	115	4 ea.	Nut
	116	4 ea.	Screw
	117	1 ea.	Barrier
	118	1 ea.	Base
	119	4 ea.	Screw
	120	1 ea.	Motor
	121	1 ea.	Bushing
	122	1 ea.	Interconnect Cord
	123	1 ea.	Impeller
	124	1 ea.	Cover
	125	1 ea.	Circuit Board Assy
	126	1 ea.	Capacitor
	127	1 ea.	Spacer
93829			Pump (w/ Integral Heater)
	113	1 ea.	Shaft Seal
	114	1 ea.	O-Ring
	115	4 ea.	Nut
	116	4 ea.	Screw
	117	1 ea.	Barrier
	118	1 ea.	Base
	119	4 ea.	Screw
	120	1 ea.	Motor
	123	1 ea.	Impeller
	124	1 ea.	Cover
	125	1 ea.	Circuit Board Assy
	126	1 ea.	Capacitor
	127	1 ea.	Spacer

****Finish/color code must be specified when ordering.**

SERVICE KITS

PART NO.	ITEM	QTY.	DESCRIPTION	
60937			Pump	
	113	1 ea.	Shaft Seal	
	128	4 ea.	Bolt	
	130	1 ea.	Motor	
	132	1 ea.	Impeller	
	133	1 ea.	Slinger	
	134	1 ea.	Volute Assy	
	135	1 ea.	End Cap	
	136	1 ea.	Shim Kit	
	137	1 ea.	O-Ring	
	138	1 ea.	Cover	
	139	6 ea.	Screw	
	140	2 ea.	Screw	
	60910			Pump
113		1 ea.	Shaft Seal	
128		4 ea.	Bolt	
129		1 ea.	Motor	
131		1 ea.	Impeller	
133		1 ea.	Slinger	
134		1 ea.	Volute Assy	
135		1 ea.	End Cap	
136		1 ea.	Shim Kit	
137		1 ea.	O-Ring	
138		1 ea.	Cover	
139		6 ea.	Screw	
140		2 ea.	Screw	
94270				Pulse Generator
	153	1 ea.	Bracket	
	154	4 ea.	Screw	
	155	1 ea.	Can	
	156	1 ea.	Rotor	
	157	1 ea.	O-Ring	
	158	1 ea.	Shaft Assy	
	159	1 ea.	Spacer	
	160	1 ea.	Motor	
	161	4 ea.	Screw	
	93836			1/2" Tube Kit
		165	1 ea.	Tube
			2 ea.	Coupling

****Finish/color code must be specified when ordering.**