

Door Schedule
Medical Clinic Building

Door #	Room Name	Size Width x Height x Thickness	Label	Material	Door	Frame	Detail	Jamb	Head	Sill	Door	Height	REMARKS
--------	-----------	---------------------------------------	-------	----------	------	-------	--------	------	------	------	------	--------	---------

FIRST FLOOR

FIRST FLOOR - COMMON AREAS

C-1000	LOBBY	Slider/ Breakout 14'-0"w. X 7'-8"h.		AL / GLASS	AL				19/A10.2	11/A10.1	A	45	Exterior Slider/Breakout AO, AL, MS, Access General, Time of Day, Key switch and Safety, Safety Glass
C-1000A	LOBBY	Slider/ Breakout 9'-0"w. X 7'-8"h.		AL / GLASS	AL				19/A10.2	11/A10.1	I	1	Exterior AO, AL, MS, Access General, Time of Day, Key switch and Safety, Safety Glass
C-1000B	LOBBY / ORTHO	PR 3'-0" X 7'-6" X 1 3/4"		SCW / GLASS	HM		1/A10.1		1/A10.1	8/A10.1	H	4	HQ, V, KP, FB, Clear
C-1002	WOMEN	3'-0" X 7'-6" X 1 3/4"		SCW / GLASS	HM		1/A10.1		1/A10.1	18/A10.1	G	44	CK, KP, PP, V, FG, Safety Glass, Clear
C-1003	MEN	3'-0" X 7'-6" X 1 3/4"		SCW / GLASS ADD: AL, PP, V, FG, Safety Glass, Clear	HM		1/A10.1		1/A10.1	18/A10.1	G	44	CK, KP, PP, V, FG, Safety Glass, Clear
C-1005	RECEPTION ALCOVE	3'-0" X 7'-6" X 1 3/4"		SCW / GLASS SCW Latches	HM		1/A10.1		1/A10.1	8/A10.1	C	9	PP, FT, Clear
C-1006	CONSULT	3'-6" X 7'-6" X 1 3/4"		SCW	AL		5/A10.1		5/A10.1	8/A10.1	C	24	
C-1006A	CONSULT	3'-0" X 7'-6"		CASED OPENING	HM					19A10.1			
C-1007	CONSULT	3'-0" X 7'-6" X 1 3/4"		SCW	AL		5/A10.1		5/A10.1	8/A10.1	G	25	
C-1007A	CONSULT	3'-0" X 7'-6"		CASED OPENING	HM					19A10.1			
C-1008	CONSULT	3'-0" X 7'-6" X 1 3/4"		SCW	AL		5/A10.1		5/A10.1	8/A10.1	C	25	
C-1008A	CONSULT	3'-0" X 7'-6"		CASED OPENING	HM					19A10.1			
C-1009	RECORDS WORKROOM	3'-0" X 7'-6" X 1 3/4"		SCW / GLASS	HM		1/A10.1		1/A10.1	19A10.1	G	18	KP, V, FG, Clear, Safety Glass
C-1009A	RECORDS WORKROOM	3'-0" X 7'-6" X 1 3/4"		SCW / GLASS	HM		1/A10.1		1/A10.1	9/A10.1	G	9	PP, FT, V, FG, Safety Glass, Clear
C-1010	WHEELCHAIR ALCOVE	3'-0" X 7'-6" X 1 3/4"		SCW	AL		5/A10.1		5/A10.1	8/A10.1	C	9	PP, FT, PP, KP, Clear
C-1011	CORRIDOR	3'-0" X 7'-6" X 1 3/4"		SCW	HM		1/A10.1		1/A10.1	9/A10.1	C	9	PP, FT, PP, KP, Clear

Door Schedule
 Doors 12
 Frames 10

Door Schedule
Medical Clinic Building

Door #	Room Name	Size Width x Height x Thickness	Label	Material	Frame	Detail	Jamb	Head	Sill	Door	Hdw	REMARKS
C-1012	STAFF TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	7/A10.1	C	39	CK, RP
C-1013	CONFERENCE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	38	RP
C-1014	DATA/TELECOM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	9	RP ES, Clear
C-1015	ELECTRICAL	4'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	19	CH, RP
C-1018	MECHANICAL	PR 3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	E	20	AT, RP Exterior, PR both sides, MR, TB, MS, DE, CB on both sides, Clear
C-1019	VESTIBULE	PR 3'-0" X 7'-8" X 1 3/4"		AL/GLASS	AL				11/A10.1	B	2	
C-1019A	VESTIBULE	PR 3'-0" X 7'-6" X 1 3/4"		AL/GLASS	AL	5/A10.1	5/A10.1	5/A10.1	8/A10.1	B	5	Safety Glass, Clear
C-1021	SOILED HOLDING	3'-6" X 7'-0" X 1 3/4"	45 min.	SCW	HM	2/A10.1	2/A10.1	2/A10.1	19/A10.1	C	10	RP ES, MR, RP, Clear
C-1022	HOUSEKEEPING	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	11	RP ES, MR, RP, Clear
C-1023	CLEAN SUPPLIES	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	11	RP ES, MR, RP, Clear
C-1023A	SPRINKLER RISER	3'-0" X 7'-0" X 1 3/4"	60 min.	SCW	HM	2/A10.1	2/A10.1	2/A10.1	19/A10.1	C	19	RP, Clear
FIRST FLOOR- ADMIN OFFICES												
C-1103	ADMIN CORRIDOR	3'-0" X 7'-0" X 1 3/4"		SCW/GLASS	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	G	26	RP, M-FG, Safety Glass, Clear
C-1102	COPY	4'-0" X 7'-0"		CASED OPENING	HM							
C-1102A	COPY	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	25	
C-1104	ADMIN CORRIDOR	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	9	RP ET, RP, Clear
C-1105	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	7/A10.1	C	39	CK, RP, MR
C-1107	ADMIN OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	27	CK
C-1108	CONFERENCE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	27	CK
C-1109	ADMIN OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	27	CK
C-1110	ADMIN OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	27	CK
FIRST FLOOR- ORTHO CLINIC												
C-1200	ORTHO WAITING	3'-6" X 7'-8" X 1 3/4"		SCW	AL	5/A10.1	5/A10.1	5/A10.1	9/A10.1	C	8	RP, ET, RR, RP, RP, Clear
C-1200A	ORTHO WAITING	3'-6" X 7'-8" X 1 3/4"		SCW	AL	5/A10.1	5/A10.1	5/A10.1	9/A10.1	C	8	RP, ET, RR, RP, RP, Clear
C-1201	ORTHO CHECK-IN	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	27	CK

Door Schedule

Doors 21 Frames 19

Door Schedule
Medical Clinic Building

Door #	Room Name	Size Width x Height x Thickness	Label	Material	Frame	Jamb	Head	Sill	Door	Hdw	REMARKS
C-1201A	ORTHO CHECK-IN	3'-0" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-1204	X-RAY WAITING	5'-0" X 8'-0"		CASED OPENING	HM			19A10.1			
C-1205	DRESSING	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19A10.1	C	39	CK
C-1205A	DRESSING	3'-0" X 7'-0" X 1 3/4"		SCW/IL	HM/IL	1/A10.1sim	1/A10.1sim	19A10.1	C	41	CK, LL, KP Clear
C-1206	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C	40	CK, KP, MP, Threshold Hinges
C-1207	X-RAY	4'-0" X 7'-0" X 1 3/4"		SCW/IL	HM/IL	1/A10.1sim	1/A10.1sim	19A10.1	C	29	LL, CH, KP
C-1209	ORTHO MGR'S OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-1213	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C	39	CK, KP, MP
C-1214	TOILET	3'-4" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C	42	CK, KP, MP
C-1216	CASTING	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19A10.1	C	33	CK, MP
C-1216A	CASTING	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19A10.1	C	21	CK, MP, KP
C-1217	CASTING	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19A10.1	C	33	CK, MP
C-1217A	CASTING	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19A10.1	C	21	CK, MP, KP
C-1218	DME	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19A10.1	C	21	KP
C-1219	X-RAY WAITING	5'-0" X 8'-0"		CASED OPENING	HM			19A10.1			
C-1220	DRESSING	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19A10.1	C	39	CK
C-1220A	DRESSING	3'-0" X 7'-0" X 1 3/4"		SCW/IL	HM/IL	1/A10.1sim	1/A10.1sim	19A10.1	C	41	CK, LL, KP, Clear
C-1221	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C	40	CK, KP, MP, Threshold Hinges
C-1222	X-RAY	4'-0" X 7'-0" X 1 3/4"		SCW/IL	HM/IL	1/A10.1sim	1/A10.1sim	19A10.1	C	29	CK, LL, KP
C-1225	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1226	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1227	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1228	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1229	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1230	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19A10.1	C	34	CK

Door Schedule

Doors 23 **Frames 25**

Door Schedule
Medical Clinic Building

Door #	Room Name	Size Width x Height x Thickness	Label	Material	Frame	Detail	Jamb	Head	Sill	Door	Hdw	REMARKS
C-1231	EXAM	3'-6" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1232	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1233	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1234	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1235	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1236	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1239	CLOSET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	12	FT, ES, KP, Closer
C-1241	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	7/A10.1	C	39	CK, KP, MP
C-1242	DR'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-1243	DR'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-1244	ASST'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-1245	DR'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-1246	DR'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-1247	DR'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-1248	CORRIDOR	3'-0" X 7'-0" X 1 3/4"		SCW/GLASS	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	G	9	FT, W, FS, Safety Glass, KP, PG, Closer
C-1250	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	7/A10.1	C	43	CK, KP, MP
C-1252	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1253	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1254	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1255	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1256	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1257	EXAM	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1258	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1259	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1260	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1261	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1262	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19A10.1	C	34	CK

Days 21

Frames 21

Door Schedule
Medical Clinic Building

Door #	Room Name	Size Width x Height x Thickness	Label	Material	Frame	Jamb	Head	Sill	Door	Hdw	REMARKS
C-1263	EXAM	3'-0" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	19A10.1	C	34	CK
C-1264	CORRIDOR	4'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19A10.1	C	28	CH, KP, Closer
C-1268	CLOSET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19A10.1	C	12	PS, ES, KP, Closer
C-1269	DR'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-1270	DR'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-1271	ASST'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-1272	DR'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-1273	DR'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-1274	STAFF TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C	39	CK, KP, MP
C-1275	STAFF BREAKROOM	3'-0" X 7'-0" X 1 3/4"		SCW/GLASS	HM	1/A10.1	1/A10.1	19A10.1	G	26	VJFG, Safety Glass, KP, Closer
FIRST FLOOR STAIRS											
C-ST 1-1	STAIR 1	3'-0" X 7'-6" X 1 3/4"	90 min.	SCW / GLASS	HM	3/A10.1	3/A10.1	8/A10.1	D	6	VJ, MP, KP, PB, Closer, Labeled Wire Glass
C-ST 1-1A	STAIR 1	3'-0" X 7'-8" X 1 3/4"		ALUM/ GLASS	AL	16/A10.2		11/A10.1	F	3	Exterior, ML, DE, TB, MS, Safety Glass, Closer
C-ST 2-1	STAIR 2	3'-0" X 7'-6" X 1 3/4"	90 min.	SCW / GLASS	HM	3/A10.1	3/A10.1	9/A10.1	D	7	VJ, MP, KP, PB, Labeled Wire Glass, Closer
SECOND FLOOR											
SECOND FLOOR - COMMON AREAS											
C-2000	LOBBY/ PULMONOLOGY	PR 3'-0" X 7'-6" X 1 3/4"		SCW / GLASS	HM	1/A10.1	1/A10.1	8/A10.1	H	4	HO, VJ, KP, PB, Closer
C-2000A	LOBBY / OB/GYN	PR 3'-0" X 7'-6" X 1 3/4"		SCW / GLASS	HM	1/A10.1	1/A10.1	8/A10.1	H	4	HO, VJ, KP, PB, Closer
C-2002	WOMEN	3'-0" X 7'-6" X 1 3/4"		SCW / GLASS	HM	1/A10.1	1/A10.1	18/A10.1	G	44	CK, KP, PP, VJ, FG, Safety Glass, Closer
C-2003	MEN	3'-0" X 7'-6" X 1 3/4"		SCW / GLASS	HM	1/A10.1	1/A10.1	18/A10.1	G	44	CK, KP, PP, VJ, FG, Safety Glass, Closer

Doors 18 Frames 110

Door Schedule
Medical Clinic Building

Door #	Room Name	Size Width x Height x Thickness	Label	Material	Door	Frame	Detail	Jamb	Head	Sill	Door	Hdw	REMARKS
C-2002	ELEV. CONTROL	3'-0" X 7'-6" X 1 3/4"	45 min.	SCW	HM	2/A10.1	2/A10.1	19/A10.1	C	15	PR, ES, KP, Closer		
C-2005	CORRIDOR	3'-0" X 7'-6" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	9	PR, ES, ET, PR, KP, Closer		
C-2006	STAFF TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C	39	CK, KP		
C-2007	PROCEDURE	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	35	CK, KP		
C-2008	DATA/TELECOM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	9	PR		
C-2009	ELECTRICAL	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	19	GH, KP		
C-2011	MECHANICAL	PR 3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	E	20	AT, KP		
C-2011A	MECHANICAL	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	22	AT, KP		
C-2014	SOILED HOLDING	3'-6" X 7'-0" X 1 3/4"	45 min.	SCW	HM	2/A10.1	2/A10.1	19/A10.1	C	10	PR, ES, MP, KP, Closer		
C-2015	HOUSEKEEPING	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	11	PR, ES, MP, KP, Closer		
C-2016	CLEAN SUPPLIES	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	11	PR, ES, MP, KP, Closer		
C-2017	ELEV. CONTROL	3'-6" X 7'-0" X 1 3/4"	45 min.	SCW	HM	2/A10.1	2/A10.1	19/A10.1	C	10	PR, ES, MP, KP, Closer		
SECOND FLOOR - PULMONOLOGY CLINIC													
C-2100	PUM WAITING	3'-6" X 7'-6" X 1 3/4"		SCW	AL	5/A10.1	5/A10.1	9/A10.1	C	8	PR, ET, RR, PR, KP, Closer		
C-2100A	PUM WAITING	3'-6" X 7'-6" X 1 3/4"		SCW	AL	5/A10.1	5/A10.1	9/A10.1	C	8	PR, ET, RR, PR, KP, Closer		
C-2101	PUM CHECK-IN	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	27	CK		
C-2104	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C	43	CK, KP, MP		
C-2107	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C	43	CK, KP, MP		
C-2108	SUPPLIES	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	9	PR, ES, KP, Closer		
C-2109	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C	39	CK, KP, MP		
C-2111	SUPPLIES	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	9	PR, ES, KP, Closer		
C-2112	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C	43	CK, KP, MP, Throwback Hinges		
C-2114	PROCEDURE	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	35	CK		
C-2115	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	CK		

Doors 24 Frames 21

Door Schedule
Medical Clinic Building

Door #	Room Name	Size Width x Height x Thickness	Label	Material	Frame	Detail	Head	Sill	Door	Hdw	REMARKS
C-2116	EXAM	3'-6" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	19/A10.1	C	35	CK
C-2117	EXAM	3'-0" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	19/A10.1	C	36	CK
C-2118	EXAM	3'-0" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	19/A10.1	C	36	CK
C-2119	EXAM	3'-0" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	19/A10.1	C	36	CK
C-2120	EXAM	3'-0" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	19/A10.1	C	36	CK
C-2121	EXAM	3'-0" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	19/A10.1	C	36	CK
C-2122	EXAM	3'-0" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	19/A10.1	C	36	CK
C-2123	EXAM	3'-0" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	19/A10.1	C	36	CK
C-2124	EXAM	3'-0" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	19/A10.1	C	36	CK
C-2125	EXAM	3'-0" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	19/A10.1	C	36	CK
C-2126	EXAM	3'-6" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	19/A10.1	C	35	CK
C-2129	TOILET	3'-0" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	7/A10.1	C	39	CK, KP, MP
C-2131	CLOSET	3'-0" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	19/A10.1	C	9	ES, KP, Closer
C-2134	TOILET	3'-0" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	7/A10.1	C	39	CK, KP, MP
C-2135	STAFF BREAKROOM	3'-0" X 7'-0" X 1 3/4"		SCW/GLASS	HM	1/A10.1	1/A10.1	19/A10.1	G	26	VF, FG, Safety Glass, KP, Closer
C-2136	DRS. OFFICE	3'-0" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-2137	N. P.'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-2138	DRS. OFFICE	3'-0" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-2139	DRS. OFFICE	3'-0" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-2140	MGR'S OFFICE	3'-0" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	9/A10.1	C	27	CK
SECOND FLOOR - OB/GYN CLINIC											
C-2200	OB/GYN WAITING	3'-6" X 7'-6" X 1 3/4"		Door	AL	5/A10.1	5/A10.1	9/A10.1	C	8	ET, RR, RB, KP, Closer
C-2200A	OB/GYN WAITING	3'-6" X 7'-6" X 1 3/4"		Door	AL	5/A10.1	5/A10.1	9/A10.1	C	8	ET, RR, RB, KP, Closer
C-2201	OB/GYN CHECK-IN	3'-0" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-2201A	OB/GYN CHECK-IN	3'-0" X 7'-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	9/A10.1	C	27	CK

Door Schedule

Doors 24 Frames 22

All C-2210A 08 SUN OFFICE 3-0" x 7-0" x 1 3/4" SCW HM 1/A10.1 1/A10.1 1/A10.1 1/A10.1 1/A10.1 19/A10.1 C 36 CK
 → mored per APPENDIX #1

Medical Clinic Building

Door #	Room Name	Size Width x Height x Thickness	Label	Material	Frame	Jamb	Head	Sill	Door Hdw	REMARKS
C-2204	TOILET	3-0" X 7-0" X 1 3/4"		Door	HM	1/A10.1	1/A10.1	7/A10.1	C 43	CK, KP, MP, Threshold Hinges
C-2207	TOILET	3-0" X 7-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C 43	CK, KP, MP, Threshold Hinges
C-2208	ULTRASOUND	3-4" X 7-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C 33	CK
C-2209	TOILET	3-0" X 7-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C 39	CK, KP, MP
C-2210	OB/GYN MGRS. OFFICE	3-0" X 7-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C 27	CK
C-2211	TOILET	3-0" X 7-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C 43	CK, KP, MP
C-2212	SUPPLIES	3-0" X 7-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C 9	ES, KP, Clear
C-2213	CORRIDOR	3-0" X 7-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C 30	KP, MP, EG, CH, Clear
C-2214	TOILET	3-0" X 7-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C 43	CK, KP, MP
C-2215	TOILET	3-0" X 7-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C 39	CK, KP, MP
C-2216	SUPPLIES	3-0" X 7-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C 9	ES, KP, Clear
C-2217	PHLEBOTOMY	4-0" X 7-0"		CASED OPENING	HM			19/A10.1		
C-2217A	PHLEBOTOMY	4-0" X 7-0"		CASED OPENING	HM			19/A10.1		
C-2218	SPECIMEN TESTING	3-0" X 7-0" X 1 3/4"	45 min.	SCW/GLASS	HM	2/A10.1	2/A10.1	19/A10.1	C 31	KP, CK, Clear
C-2219	TOILET	3-0" X 7-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C 39	CK, KP, MP
C-2221	TOILET	3-0" X 7-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C 43	CK, KP, MP
C-2222	SUPPLIES	3-0" X 7-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C 9	ES, KP, Clear
C-2223	ULTRASOUND	3-4" X 7-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C 33	CK
C-2224	TOILET	3-0" X 7-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C 39	CK, KP, MP
C-2225	SUPPLIES	3-0" X 7-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C 9	ES, KP, Clear
C-2226	TOILET	3-0" X 7-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C 39	CK, KP, MP
C-2228	EXAM	3-0" X 7-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C 36	CK
C-2229	EXAM	3-0" X 7-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C 36	CK
C-2230	EXAM	3-0" X 7-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C 36	CK
C-2231	EXAM	3-0" X 7-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C 36	CK

Doors of 24 Frames of 26

Door Schedule
Medical Clinic Building

Door #	Room Name	Size Width x Height x Thickness	Label	Material	Frame	Detail	Jamb	Head	Sill	Door Hdw	REMARKS
C-2232	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	OK
C-2233	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	OK
C-2234	EXAM	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 35	OK
C-2235	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	OK
C-2236	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	OK
C-2237	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	OK
C-2238	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	OK
C-2239	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	OK
C-2242	CLOSET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 12	RS, ES, KP, Closer
C-2244	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	7/A10.1	C 39	CK, KP, MP
C-2245	DRS. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C 27	OK
C-2246	N. P.'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C 27	OK
C-2247	DRS. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C 27	OK
C-2248	DRS. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C 27	OK
C-2249	CORRIDOR	3'-0" X 7'-0" X 1 3/4"		SCW/GLASS	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	G 14	Soft sides, ET, PB, Closer, W/FG, Safety Glass, KP
C-2251	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	OK
C-2252	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	OK
C-2253	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	OK
C-2254	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	OK
C-2255	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	OK
C-2256	EXAM	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 35	OK
C-2257	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	OK
C-2258	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	OK
C-2259	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	OK
C-2260	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	OK
C-2261	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	OK

Door Schedule
Doors 26
Frames 26
Printed 4/29/2010

Door Schedule
Medical Clinic Building

Door #	Room Name	Size Width x Height x Thickness	Label	Material	Door	Frame	Detail	Jamb	Head	Sill	Door	Hdw	REMARKS
C-2262	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	36	CK
C-2265	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	1/A10.1	7/A10.1	C	39	CK, KP, MP
C-2267	CLOSET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	26	PK, ES, KP, Clear
C-2268	CONSULT/FUTURE PROCEDURE	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	35	CK
C-2269	DRS. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-2270	N.P.S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-2271	DRS. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-2272	DRS. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-2273	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	1/A10.1	7/A10.1	C	39	CK, KP, MP
C-2274	STAFF BREAKROOM	3'-0" X 7'-0" X 1 3/4"		SCW/GLASS	HM	1/A10.1	1/A10.1	1/A10.1	1/A10.1	19/A10.1	G	26	VL, FG, Safety Glass, KP, Clear
SECOND FLOOR STAIRS													
C-ST 1-2	STAIR 1	3'-0" X 7'-6" X 1 3/4"	40 min.	SCW / GLASS	HM	3/A10.1	3/A10.1	3/A10.1	3/A10.1	8/A10.1	D	6	VL, MP, KP, PB, Clear Labeled Wire Glass
C-ST 2-2	STAIR 2	3'-0" X 7'-0" X 1 3/4"	40 min.	SCW / GLASS	HM	3/A10.1	3/A10.1	3/A10.1	3/A10.1	19/A10.1	D	6	PK, ES, MP, PB, ET, VL, MP, KP, Clear, Labeled Wire Glass
THIRD FLOOR													
THIRD FLOOR - COMMON AREAS													
C-3000	LOBBY/ ENT	PR 3'-0" X 7'-6" X 1 3/4"		SCW / GLASS	HM	1/A10.1	1/A10.1	1/A10.1	1/A10.1	8/A10.1	H	4	HO, VL, KP, PB, Clear
C-3000A	LOBBY/ INT MED	PR 3'-0" X 7'-6" X 1 3/4"		SCW / GLASS	HM	1/A10.1	1/A10.1	1/A10.1	1/A10.1	8/A10.1	H	4	HO, VL, KP, PB, Clear
C-3002	WOMEN	3'-0" X 7'-6" X 1 3/4"		SCW / GLASS	HM	1/A10.1	1/A10.1	1/A10.1	1/A10.1	18/A10.1	G	44	CK, KP, PR, VL, FG, Safety Glass, Clear
C-3003	MEN	3'-0" X 7'-6" X 1 3/4"		SCW / GLASS	HM	1/A10.1	1/A10.1	1/A10.1	1/A10.1	18/A10.1	G	44	CK, KP, PR, VL, FG, Safety Glass, Clear
C-3004	ELEV. CONTROL	3'-6" X 7'-6" X 1 3/4"	45 min.	SCW	HM	2/A10.1	2/A10.1	2/A10.1	2/A10.1	19/A10.1	C	15	PK, ES, KP, Clear
C-3005	CORRIDOR	3'-0" X 7'-6" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	9	PK, ES, KP, Clear
C-3006	STAFF TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	1/A10.1	7/A10.1	C	39	CK, KP

See ADD. 1: 300

Door Schedule

DOORS 21

FRAMES 19

Door Schedule
Medical Clinic Building

Door #	Room Name	Size Width x Height x Thickness	Label	Material	Door	Frame	Jamb	Head	Sill	Door Hdw	REMARKS
C-3007	CONFERENCE	3-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		C 38	KP
C-3008	DATA/TELECOM	3-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		C 9	PK, ES, Clear
C-3009	ELECTRICAL	3-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		C 19	KP
C-3011	MECHANICAL	PR 3-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		E 20	AT, KP
C-3011A	MECHANICAL	3-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		C 22	AT, KP
C-3014	SOILED HOLDING	3-6" X 7'-0" X 1 3/4"	45 min.	SCW	HM	2/A10.1	2/A10.1	19/A10.1		C 10	PK, ES, MP, KP, Clear
C-3015	HOUSEKEEPING	3-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C 11	PK, ES, MP, KP, Clear
C-3016	CLEAN SUPPLIES	3-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C 11	PK, ES, MP, KP, Clear
THIRD FLOOR - ENT CLINIC											
C-3100	ENT WAITING	3-6" X 7'-6" X 1 3/4"		SCW	AL	5/A10.1	5/A10.1	9/A10.1		C 8	PK, ET, RR, PK, KP, Clear
C-3100A	ENT WAITING	3-6" X 7'-6" X 1 3/4"		SCW	AL	5/A10.1	5/A10.1	9/A10.1		C 8	PK, ET, RR, PK, KP, Clear
C-3101	ENT CHECK-IN	3-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		C 27	CK
C-3102	TOILET	3-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1		C 43	CK, KP
C-3107	AUDIOLOGIST	3-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		C 23	AT, CK
C-3108	AUDIOLOGY TEST.	3-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C 37	AT, CK
C-3109A	SUPPLIES	3-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C 9	PK, ES, KP, Clear
C-3110	TOILET	3-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1		C 39	CK, KP
C-3111	SCALE	3-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C 9	PK, ES, KP, Clear
C-3112	SUPPLIES	3-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C 9	PK, ES, KP, Clear
C-3113	TOILET	3-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1		C 43	CK, KP, MP, Threshold Highrise
C-3115	PROCEDURE	3-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C 36	CK
C-3116	EXAM	3-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C 36	CK
C-3117	EXAM	3-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C 36	CK
C-3118	EXAM	3-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C 36	CK
C-3119	EXAM	3-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C 36	CK
C-3120	EXAM	3-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C 36	CK

Door Schedule

DOORS 85

FRAMES 25

Door Schedule
Medical Clinic Building

Door #	Room Name	Size Width x Height x Thickness	Label	Material	Frame	Detail	Jamb	Head	Sill	Door	Hdw	REMARKS
C-3121	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C	36	CK
C-3122	EXAM	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C	35	CK
C-3123	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C	36	CK
C-3124	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C	36	CK
C-3125	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C	36	CK
C-3126	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C	36	CK
C-3127	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C	36	CK
C-3128	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1		C	39	CK, KP, MP
C-3132	SOILED HOLDING	3'-0" X 7'-0" X 1 3/4"	45 min.	SCW	HM	2/A10.1	2/A10.1	19/A10.1		C	16	ES, KP, MP, Clear V.G. Safety Glass, KP, Clear
C-3133	STAFF BREAKROOM	3'-0" X 7'-0" X 1 3/4"		SCW/GLASS	HM	1/A10.1	1/A10.1	19/A10.1		G	26	
C-3134	DR'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		C	27	CK
C-3135	ALLERGIST'S OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		C	27	CK
C-3136	DR'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		C	27	CK
C-3137	DR'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		C	27	CK
C-3138	MGR'S OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		C	27	CK
C-3140	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1		C	39	CK, KP, MP
C-3141	CLOSET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C	12	ES, KP, Clear
THIRD FLOOR- INTERNAL MEDICINE CLINIC												
C-3200	INT MED WAITING	3'-6" X 7'-6" X 1 3/4"		SCW	AL	5/A10.1	5/A10.1	9/A10.1		C	8	ET, RR, PG, KP, Clear
C-3200A	INT MED WAITING	3'-6" X 7'-6" X 1 3/4"		SCW	AL	5/A10.1	5/A10.1	9/A10.1		C	8	ET, RR, PG, KP, Clear
C-3201	INT MED CHECK-IN	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		C	27	CK
C-3201A	INT MED CHECK-IN	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		C	27	CK
C-3204	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1		C	43	CK, KP, MP, Throwback Hinges
C-3207	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1		C	43	CK, KP, MP, Throwback Hinges
C-3208	SUPPLIES	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C	17	ES, KP, Clear

Doors 24 **Frames 22**

Door Schedule
Medical Clinic Building

Door #	Room Name	Size Width x Height x Thickness	Label	Material	Frame	Detail	Jamb	Head	Sill	Door Hdw	REMARKS
C-3209	INT MED. SUPV. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C 27	CK
C-3210	INT MED MGR. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C 27	OK
C-3211	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	7/A10.1	C 43	CK, K9, MP
C-3212	SUPPLIES	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 9	ES, K9, Closer
C-3213	CORRIDOR	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 30	K9
C-3214	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	7/A10.1	C 43	CK, K9, MP
C-3215	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	7/A10.1	C 39	CK, K9, MP
C-3216	PHLEBOTOMY	4'-0" X 7'-0"		CASED OPENING	HM				19/A10.1		
C-3216A	PHLEBOTOMY	4'-0" X 7'-0"		CASED OPENING	HM				19/A10.1		
C-3217	SPECIMEN TESTING	3'-0" X 7'-0" X 1 3/4"	45 min.	SCW/ GLASS	HM	2/A10.1	2/A10.1	2/A10.1	19/A10.1	C 31	K9, CK, Closer
C-3218	SUPPLIES	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 9	ES, K9, Closer
C-3219	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	7/A10.1	C 39	CK, K9, MP
C-3220	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	7/A10.1	C 43	CK, K9, MP
C-3222	SUPPLIES	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 9	ES, K9, Closer
C-3223	SUPPLIES	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 9	ES, K9, Closer
C-3224	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	7/A10.1	C 39	CK, K9, MP
C-3226	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	CK
C-3227	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	CK
C-3228	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	CK
C-3229	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	CK
C-3230	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	CK
C-3231	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 35	CK
C-3232	EXAM	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	CK
C-3233	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	CK
C-3234	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	CK
C-3235	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C 36	CK

Door Schedule
 Doors 24
 Frames 26

Door Schedule
Medical Clinic Building

Door #	Room Name	Size Width x Height x Thickness	Label	Material	Frame	Detail	Jamb	Head	Sill	Door	Hdw	REMARKS
C-3236	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-3237	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-3239	CORRIDOR	3'-0" X 7'-0" X 1 3/4"		SCW/GLASS	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	G	74	PR both sides, ET, PI, Clear, KP, YL-FG, Safety Glass
C-3241	CLOSET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	12	FR, ES, KP, Clear
C-3243	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	7/A10.1	C	39	OK, KP, MP
C-3244	DRS. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	27	OK
C-3245	N.P.'S OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	27	OK
C-3246	DRS. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	27	OK
C-3247	DRS. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	27	OK
C-3249	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-3250	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-3251	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-3252	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-3253	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-3254	EXAM	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	35	OK
C-3255	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-3256	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-3257	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-3258	EXAM	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	35	OK
C-3259	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-3260	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-3263	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	7/A10.1	C	39	OK, KP, MP
C-3265	CLOSET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	9	FR, ES, KP, Clear
C-3266	PROCEDURE	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	35	OK
C-3267	DRS. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	27	OK
C-3268	N.P.'S OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	27	OK

Doors 26 Frames 26

Door Schedule
Medical Clinic Building

Door #	Room Name	Size Width x Height x Thickness	Label	Material	Door	Frame	Jamb	Head	Sill	Door	Hdw	REMARKS
C-3269	DR'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	27	OK
C-3270	DR'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	27	OK
C-3271	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	7/A10.1	C	39	OK, NP, MP
C-3272	STAFF BREAKROOM	3'-0" X 7'-0" X 1 3/4"		SCW/GLASS	HM	1/A10.1	1/A10.1	19/A10.1	19/A10.1	G	26	VL-FG, Safety Glass, KP, Close
THIRD FLOOR STAIRS												
C-571-3	STAIR 1	3'-0" X 7'-4" X 1 3/4"	90 min.	SCW / GLASS	HM	3/A10.1	3/A10.1	3/A10.1	8/A10.1	D	6	VL, MP, KP, FG, Glass, Labeled Wire Glass
C-572-3	STAIR 2	3'-0" X 7'-0" X 1 3/4"	90 min.	SCW / GLASS	HM	3/A10.1	3/A10.1	3/A10.1	19/A10.1	D	6	90 min. Labeled Wire Glass, VL, MP, KP, Labeled Wire Glass

Doors & Frames to

SECTION 08746

AUTOMATIC OPERATORS

PART 1 GENERAL

- 1.1 SECTION INCLUDES
- A. Electromechanical, heavy duty, full-energy ANSI 156-10 powered door operators, opening force not exceeding 14 lb-force (62 N), with door mounted safety sensors (Sentrex or B.E.A. Paralex 2)
- 1.2 RELATED SECTIONS
- A. Section 08212: Flush Wood Doors
 - B. Section 08410: Aluminum Doors and Frames
 - C. Section 08710: Door Hardware
 - D. Division 16 - Electrical
- 1.3 REFERENCES
- A. ANSIBHMA A156.19 - American National Standard for Power Assist & Low-Energy Power Operated Doors.
 - B. UL 325 - Standard for Door, Drapery, Gate, Louver and Window Operators and Systems.
- 1.4 SUBMITTALS
- A. Submit under provisions of Section 01300.
 - B. Product Data: Manufacturer's catalog data, detail sheets and specifications.
 - C. Shop Drawings: Prepared specifically for this project; show dimensions of operators and interface with other products.
 - D. Operating and Maintenance Data: Operating and maintenance instructions, parts lists and wiring diagrams.
- 1.5 QUALITY ASSURANCE
- A. Installer Qualifications: Factory-trained with minimum 3 years experience.

PART 2 PRODUCTS

2.1 MANUFACTURERS

- A. Acceptable manufacturers:
 1. Stanley: Magic Swing Operator
 2. Horton
 3. Besam
 4. Substitutions: Under provisions of Section 01600.
- B. Requests for substitutions will be considered in accordance with provisions of Section 01600.
- C. Provide all door operators from a single manufacturer.

2.2 OPERATORS

- A. Operation: Push button, push plate, switch-activated, manual or field-programmable manual/electric power assisted Push "N" Go opening and holding; comply with ANSI A156.10 and UL 325.
 1. Close door against stop after each cycle, and hold against drafts, winds and stack pressure.
 2. Manual opening force: 14 lb-force (62 N) maximum.
 3. Closing force: 9 lb-force (26.6 N).
 4. Manual "Off/Auto/Hold-Open" switch.
 5. Fail safe: In event of power failure, make door operate manually with controlled spring close as though equipped with a #3 manual door closer, without damage to operator components.
 6. Provide adjustment by microprocessor control in a self-contained housing for:
 - a. Opening speed.
 - b. Backcheck speed.
 - c. Hold-open, from 1 to 30 seconds.
 - d. Closing speed.
 - e. Door will safely stop and reverse if an object is encountered in the opening cycle.
 - f. Delayed activation to provide 1 second delay between reception of the activation signal and actual opening of the door.
 - g. Adjustable latching from 0 to 23 degrees from fully closed position.
 - h. Alternate Action single activation to keep door open until that time activation occurs again.
 - i. Logic terminal for interface with accessories, mats, and sensors.
 - j. Sensors: Sentrex Active Presence Detector and SU-100 motion sensors, or B.E.A. Paradox 2.
- B. Equipment: Completely electromechanical; comply with ANSI A156.19 and UL 325.
 1. Control box and motor/gear box: Contained in aluminum housing; precision-machined gears and bearing seals and all-weather lubricant, mounted on vibration isolators. No exposed gears.
 2. Enclosure: Extruded header concealing all operating parts except arms and manual control switches.
 - a. 6" x 5-1/2" aluminum housing that allows for bottom loading.
 - b. Design for overhead concealed application.

<p>3.2</p> <p>INSTALLATION</p>	<p>A. Install in accordance with manufacturer's instructions; comply with ANSI A156.19.</p> <p>B. Verify that electrical service is available, properly located and of proper type.</p>
<p>3.1</p> <p>EXAMINATION</p>	<p>A. Verify that door openings and doors are properly installed and ready for installation of door operators.</p>
<p>PART 3 EXECUTION</p>	
<p>2.4</p> <p>MARKINGS</p>	<p>A. Decals: Visible from either side, instructing the user as to the operation and function of the door.</p> <p>B. Push Plate: Formed metal plate, satin finish; approximately 5" (127 mm) square with depressed marking; two recommended per opening.</p> <p>1. Material: Stainless steel.</p> <p>2. Marking: Wheelchair logo.</p> <p>B. Motion Detector: Sentrex Infrared.</p> <p>C. Card Reader: By others.</p>
<p>2.3</p> <p>ACTUATORS</p>	<p>16. Operator shall interface with prox. readers.</p> <p>15. Finish of Exposed Headers: Anodized aluminum.</p> <p>section 08710.</p> <p>14. Provide transformer if required. Check power supply furnished with hardware in section 08710.</p> <p>13. Provide sequence module 82149 as required without removal of door or operator.</p> <p>12. Provide bottom loading header for access to controls and removable components (mm) above top of door.</p> <p>11. Surface-Applied Mounting: On surface of door frame/wall, mounted 1" (25.4 mm) above top of door.</p> <p>10. Microprocessor control: 120 VAC. Do not use microswitches.</p> <p>9. Power supply required: 120 VAC, 5 amps.</p> <p>8. Service conditions: Satisfactory operation between -30 degrees F (-34 degrees C) and 160 degrees F (71 degrees C).</p> <p>7. Control circuits for actuators and safeties: Low-voltage, NEC Class II.</p> <p>6. "Off/Auto/Hold-Open" switch: Three-position rocker or key type and slide arm for top of door.</p> <p>5. Exposed arms: Factory-painted and finished to match operator enclosure.</p> <p>4. Door operating arm: Forged steel, attached at natural pivot point of door when door stops or is fully open and when breakaway is operated.</p> <p>3. Motor: DC permanent magnet motor with shielded ball bearings. Stop motor when door stops or is fully open and when breakaway is operated.</p> <p>a. Gears enclosed in gearbox.</p> <p>b. Gears: Manufactured by operator manufacturer specifically for operators.</p> <p>c. Design for interior application.</p> <p>d. Design for surface-applied application.</p> <p>e. point for clearance of arm concealing channel.</p> <p>c. Overhead concealed with butt hung hinges - maintain a 3-3/4" pivot</p>

END OF SECTION

- B. Verify that electrical connections are made correctly and with dedicated grounding.
- 3.3 ADJUST
- A. Adjust door operators for proper operation, without binding or scraping and without excessive noise.
- B. Supply Owner/Contractor with keys if required.

Door Schedule

Medical Clinic Building

ALTERNATE NUMBER 1

Door #	Room Name	Size Width x Height x Thickness	Label	Material	Frame	Detail	Jobb	Head	Sill	Door Hdw	REMARKS
--------	-----------	---------------------------------------	-------	----------	-------	--------	------	------	------	----------	---------

FOURTH FLOOR

FOURTH FLOOR - COMMON AREAS

C-4000	LOBBY	PR 3'-0" X 7'-6" X 1 3/4"		SCW / GLASS	HM	1/A10.1	1/A10.1	8/A10.1		H	4	HO, VL, KP, PB, Closer
C-4000A	LOBBY	PR 3'-0" X 7'-6" X 1 3/4"		SCW / GLASS	HM	1/A10.1	1/A10.1	8/A10.1		H	4	HO, VL, KP, PB, Closer
C-4002	WOMEN	3'-0" X 7'-6" X 1 3/4"		SCW / GLASS	HM	1/A10.1	1/A10.1	18/A10.1		G	44	CK, RP, PP, VL-FG, Safety Glass, Closer
C-4003	MEN	3'-0" X 7'-6" X 1 3/4"		SCW / GLASS	HM	1/A10.1	1/A10.1	18/A10.1		G	44	CK, RP, PP, VL-FG, Safety Glass, Closer
C-4004	ELEV. CONTROL	3'-6" X 7'-6" X 1 3/4"	45 min.	SCW	HM	2/A10.1	2/A10.1	19/A10.1		C	15	PR, ES, RP, Closer
C-4008	DATA/TELECOM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		C	9	PR, ES, Closer
C-4009	ELECTRICAL	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		C	19	KP
C-4011	MECHANICAL	PR 3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		E	20	AT, KP
C-4011A	MECHANICAL	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		C	22	AT, KP
C-4012	SHELL (TEMPORARY)	PR 3'-8" X 7'-6" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		E	20	AT, KP

FOURTH FLOOR STAIRS

C-ST1-4	STAR 1	3'-0" X 7'-6" X 1 3/4"	90 min.	SCW / GLASS	HM	3/A10.1	3/A10.1	8/A10.1		D	6	VL, MP, KP, PB, Closer, Labeled Wire Glass
C-ST2-4	STAR 2	3'-0" X 7'-0" X 1 3/4"	90 min.	SCW / GLASS	HM	3/A10.1	3/A10.1	19/A10.1		D	6	PR (inside stair), ET, PB, Closer, VL, MP, KP, Labeled Wire Glass

Doors 10 Frames 12

Door Schedule

Medical Clinic Building

ALTERNATE NUMBER 2

Door #	Room Name	Size Width x Height x Thickness	Label	Material	Door	Frame	Jamb	Head	Sill	Door	Height	REMARKS
--------	-----------	---------------------------------------	-------	----------	------	-------	------	------	------	------	--------	---------

FOURTH FLOOR

FOURTH FLOOR - COMMON AREAS

C-4000	LOBBY	PR 3'-0" X 7'-6" X 1 3/4"		SCW / GLASS	HM	1/A10.1	1/A10.1	1/A10.1	8/A10.1	H	4	HQ, VL, KP, PB, Closer
C-4000A	LOBBY	PR 3'-0" X 7'-6" X 1 3/4"		SCW / GLASS	HM	1/A10.1	1/A10.1	1/A10.1	8/A10.1	H	4	HO, VL, KP, PB, Closer
C-4002	WOMEN	3'-0" X 7'-6" X 1 3/4"		SCW / GLASS	HM	1/A10.1	1/A10.1	1/A10.1	18/A10.1	G	44	CK, KP, PP, VI-FG, Safety Glass, Closer
C-4003	MEN	3'-0" X 7'-6" X 1 3/4"		SCW / GLASS	HM	1/A10.1	1/A10.1	1/A10.1	18/A10.1	G	44	CK, KP, PP, VI-FG, Safety Glass, Closer
C-4004	ELEV. CONTROL	3'-6" X 7'-6" X 1 3/4"	45 min.	SCW	HM	2/A10.1	2/A10.1	2/A10.1	19/A10.1	C	15	PR, ES, KP, Closer
C-4005	CORRIDOR	3'-0" X 7'-6" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	9	PR, ET, PP, KP, Closer
C-4006	STAFF TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	7/A10.1	C	39	CK, KP
C-4007	CONFERENCE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	38	KP
C-4008	DATA/TELECOM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	9	PR, ES, Closer
C-4009	ELECTRICAL	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	19	KP
C-4011	MECHANICAL	PR 3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	E	20	AT, KP
C-4011A	MECHANICAL	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	22	AT, KP
C-4014	SOILED HOLDING	3'-6" X 7'-0" X 1 3/4"	45 min.	SCW	HM	2/A10.1	2/A10.1	2/A10.1	19/A10.1	C	10	PR, ES, MP, KP, Closer
C-4015	HOUSEKEEPING	3'-6" X 7'-0" X 1 3/4"		SCW	HMA	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	11	PR, ES, MP, KP, Closer
C-4016	CLEAN SUPPLIES	3'-6" X 7'-0" X 1 3/4"		SCW	HMA	1/A10.1	1/A10.1	1/A10.1	19/A10.1	C	11	PR, ES, MP, KP, Closer

FOURTH FLOOR- CLINIC 1

C-4100	WAITING	3'-6" X 7'-6" X 1 3/4"		SCW	AL	5/A10.1	5/A10.1	5/A10.1	9/A10.1	C	8	PR, ET, RR, PB, KP, Closer
C-4100A	WAITING	3'-6" X 7'-6" X 1 3/4"		SCW	AL	5/A10.1	5/A10.1	5/A10.1	9/A10.1	C	8	PR, ET, RR, PB, KP, Closer
C-4101	CHECK-IN	3'-0" X 7'-0" X 1 3/4"		SCW	HMA	1/A10.1	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-4104	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HMA	1/A10.1	1/A10.1	1/A10.1	7/A10.1	C	43	CK, KP
C-4108	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HMA	1/A10.1	1/A10.1	1/A10.1	7/A10.1	C	39	CK, KP

Door Schedule

Doors 23 Frames 18

Printed 4/29/2010

Door Schedule

Medical Clinic Building

ALTERNATE NUMBER 2

Door #	Room Name	Size Width x Height x Thickness	Label	Material	Frame	Jamb	Head	Sill	Door	Hdw	REMARKS
C-4109	SUPPLIES	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	9	PR. ES. KP, Clear
C-4110	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C	39	CKP
C-4112	SUPPLIES	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	9	PR. ES. KP, Clear
C-4113	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C	43	CK, KP, MP, Threshold Hinges
C-4115	PROCEDURE	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	35	CK
C-4116	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	CK
C-4117	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	CK
C-4118	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	CK
C-4119	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	CK
C-4120	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	CK
C-4121	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	CK
C-4122	EXAM	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	35	CK
C-4123	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	CK
C-4124	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	CK
C-4125	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	CK
C-4126	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	CK
C-4127	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	CK
C-4130	CLOSET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	12	PR. ES. KP, Clear
C-4132	SOILED HOLDING	3'-0" X 7'-0" X 1 3/4"	45 min.	SCW	HM	2/A10.1	2/A10.1	19/A10.1	C	16	PR. ES. KP, MP, Clear
C-4133	STAFF BREAKROOM	3'-0" X 7'-0" X 1 3/4"		SCW/GLASS	HM	1/A10.1	1/A10.1	19/A10.1	G	26	V-LFG, Safety Glass, No Clear
C-4134	DRS. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-4135	OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-4136	DRS. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-4137	DRS. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-4138	MGRS OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	27	CK
C-4140	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C	39	CK, KP, MP

Doors 210

Frames 210

Door Schedule

P# 7199

Door Schedule

Medical Clinic Building

ALTERNATE NUMBER 2

Door #	Room Name	Size Width x Height x Thickness	Label	Material	Frame	Detail	Jamb	Head	Sill	Door Hdw	REMARKS
FOURTH FLOOR- CLINIC 2											
C-4200	WAITING	3'-6" X 7'-6" X 1 3/4"		SCW	AL	5/A10.1	5/A10.1	9/A10.1		C	PR, ET, RR, RP, CP, Closer
C-4200A	WAITING	3'-6" X 7'-6" X 1 3/4"		SCW	AL	5/A10.1	5/A10.1	9/A10.1		C	PR, ET, RR, RP, CP, Closer
C-4201	CHECK-IN	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		C	CK
C-4201A	CHECK-IN	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		C	CK
C-4204	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1		C	CK, RP, MP, Throwback Hinges
C-4207	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1		C	CK, RP, MP, Throwback Hinges
C-4208	SUPPLIES	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C	PR, ES, RP, Closer
C-4209	SUPV. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		C	CK
C-4210	OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1		C	CK
C-4211	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1		C	CK, RP, MP
C-4212	SUPPLIES	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C	PR, ES, RP, Closer
C-4213	CORRIDOR	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C	RP
C-4214	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1		C	CK, RP, MP
C-4215	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1		C	CK, RP, MP
C-4216	PHLEBOTOMY	4'-0" X 7'-0"		CASED OPENING	HM			19/A10.1			
C-4216A	PHLEBOTOMY	4'-0" X 7'-0"		CASED OPENING	HM			19/A10.1			
C-4217	SPECIMEN TESTING	3'-0" X 7'-0" X 1 3/4"	45 min.	SCW/ GLASS	HM	2/A10.1	2/A10.1	19/A10.1		C	RP, CK, Closer
C-4218	SUPPLIES	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C	PR, ES, RP, Closer
C-4219	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1		C	CK, RP, MP
C-4220	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1		C	CK, RP, MP
C-4222	SUPPLIES	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C	PR, ES, RP, Closer
C-4223	PROCEDURE	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C	CK
C-4224	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1		C	CK, RP, MP
C-4225	SUPPLIES	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1		C	PR, ES, RP, Closer

Door Schedule

Doors 22

Frames 22

Door Schedule

Medical Clinic Building

ALTERNATE NUMBER 2

Door #	Room Name	Size Width x Height x Thickness	Label	Material	Frame	Panel	Head	Sill	Door	Hdw	REMARKS
C-4226	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-4227	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-4228	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-4229	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-4230	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-4231	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-4232	EXAM	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	35	OK
C-4233	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-4234	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-4235	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-4236	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-4237	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-4239	CORRIDOR	3'-0" X 7'-0" X 1 3/4"		SCW/GLASS	HM	1/A10.1	1/A10.1	19/A10.1	G	14	PR both sides, ET, PB, Clear, KP, W-FG, Safety Glass
C-4241	CLOSET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	12	PR, ES, KP, Clear
C-4243	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C	39	OK, KP, MP
C-4244	DR'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	27	OK
C-4245	N.P.'S OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	27	OK
C-4246	DR'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	27	OK
C-4247	DR'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-4249	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-4250	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-4251	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-4252	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-4253	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-4254	EXAM	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	35	OK
C-4255	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK

Doors 210 FRAMES 210

Door Schedule

Medical Clinic Building

ALTERNATE NUMBER 2

Door #	Room Name	Size Width x Height x Thickness	Label	Material	Frame	Jamb	Head	Sill	Door	Hdw	REMARKS
C-4256	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-4257	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-4258	EXAM	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	35	OK
C-4259	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-4260	EXAM	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	36	OK
C-4263	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C	39	OK, RP, MP
C-4265	CLOSET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	9	PR, ES, RP, Closer
C-4266	PROCEDURE	3'-6" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	19/A10.1	C	35	OK
C-4267	DR'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	27	OK
C-4268	N.P.'S OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	27	OK
C-4269	DR'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	27	OK
C-4270	DR'S. OFFICE	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	9/A10.1	C	27	OK
C-4271	TOILET	3'-0" X 7'-0" X 1 3/4"		SCW	HM	1/A10.1	1/A10.1	7/A10.1	C	39	OK, RP, MP
C-4272	STAFF BREAKROOM	3'-0" X 7'-0" X 1 3/4"		SCW/GLASS	HM	1/A10.1	1/A10.1	19/A10.1	G	26	VL-FG, Safety Glass, RP, Closer
FOURTH FLOOR STAIRS											
C-ST1-4	STAR 1	3'-0" X 7'-6" X 1 3/4"	60 min.	SCW / GLASS	HM	3/A10.1	3/A10.1	8/A10.1	D	6	VL, MP, KP, RP, Closer, Labeled Wire Glass
C-ST2-4	STAR 2	3'-0" X 7'-0" X 1 3/4"	60 min.	SCW / GLASS	HM	3/A10.1	3/A10.1	19/A10.1	D	6	PR, finish scrib, ET, RP, Closer, VL, MP, RP, Labeled Wire Glass

Doors 10 Frames 10