


LOAD GROUP REACTION TABLE

| COLUMN | LEFT COLUMN | RIGHT COLUMN | INTERIOR COLUMN 1 | INTERIOR COLUMN 2 | INTERIOR COLUMN 3 | | | | | | | | | | |
|------------|----------------|----------------|-------------------|-------------------|-------------------|------|-----|-------|------|-----|------|------|-----|-------|------|
| BASE PLATE | 6.0X10.0X0.375 | 6.0X10.0X0.375 | 6.0X12.0X0.375 | 6.0X10.5X0.375 | 6.0X12.5X0.375 | | | | | | | | | | |
| ANC. BOLTS | (4)-3/4 | (4)-3/4 | (4)-5/8 | (4)-5/8 | (4)-5/8 | | | | | | | | | | |
| LOAD GROUP | HL | VL | LL | HR | VR | LR | HI | VI | LI | H2 | V2 | L2 | H3 | V3 | L3 |
| D | 0.0 | 0.8 | 0.0 | 0.0 | 0.9 | 0.0 | 0.0 | 1.7 | 0.0 | 0.0 | 1.6 | 0.0 | 0.0 | 1.9 | 0.0 |
| C | 0.0 | 0.1 | 0.0 | 0.0 | 0.1 | 0.0 | 0.0 | 0.2 | 0.0 | 0.0 | 0.2 | 0.0 | 0.0 | 0.2 | 0.0 |
| L | 0.0 | 2.6 | 0.0 | 0.0 | 2.6 | 0.0 | 6.5 | -0.2 | 0.0 | 5.4 | -0.1 | 0.0 | 6.6 | -0.1 | 0.0 |
| W+ | -0.1 | -11.9 | 8.9 | 0.1 | -5.1 | 2.0 | 0.0 | -11.3 | 5.1 | 0.0 | -9.2 | 5.2 | 0.0 | -11.3 | 5.6 |
| W- | -0.1 | 1.6 | 0.0 | 0.1 | -5.1 | -2.4 | 0.0 | -11.3 | -5.1 | 0.0 | -9.2 | -5.3 | 0.0 | -11.3 | -5.7 |
| WR | -0.1 | -5.1 | 0.0 | 0.1 | -5.1 | 0.0 | 0.0 | -11.3 | 0.3 | 0.0 | -9.2 | 0.2 | 0.0 | -11.3 | 0.2 |
| WL | -0.1 | -5.1 | 0.0 | 0.1 | -5.1 | 0.0 | 0.0 | -11.3 | 0.3 | 0.0 | -9.2 | 0.2 | 0.0 | -11.3 | 0.2 |
| E+ | 0.0 | -0.9 | 1.3 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 |
| E- | 0.0 | 0.9 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 |

LOAD GROUP DESCRIPTION

D : DEAD LOAD
C : COLLATERAL LOAD
L : LIVE LOAD
W+ : WIND LOAD AS AN INWARD ACTING PRESSURE
W- : WIND LOAD AS AN OUTWARD ACTING SUCTION
WR : WIND FORCE FROM THE RIGHT
WL : WIND FORCE FROM THE LEFT
E+ : EARTHQUAKE FORCE ACTING INWARD
E- : EARTHQUAKE FORCE ACTING OUTWARD




LOAD GROUP REACTION TABLE

| COLUMN | LEFT COLUMN | RIGHT COLUMN | INTERIOR COLUMN 4 | INTERIOR COLUMN 5 | INTERIOR COLUMN 6 | INTERIOR COLUMN 7 | | | | | | |
|------------|----------------|----------------|-------------------|-------------------|-------------------|-------------------|-----|------|------|-----|-------|------|
| BASE PLATE | 6.0X12.5X0.375 | 6.0X12.5X0.375 | 6.0X12.5X0.375 | 6.0X12.5X0.375 | 6.0X10.5X0.375 | 6.0X12.5X0.375 | | | | | | |
| ANC. BOLTS | (4)-5/8 | (4)-5/8 | (4)-5/8 | (4)-5/8 | (4)-5/8 | (4)-5/8 | | | | | | |
| LOAD GROUP | H4 | V4 | L4 | H5 | V5 | L5 | H6 | V6 | L6 | H 7 | V 7 | L 7 |
| D | 0.0 | 1.5 | 0.0 | 0.0 | 1.9 | 0.0 | 0.0 | 1.6 | 0.0 | 0.0 | 1.7 | 0.0 |
| C | 0.0 | 0.1 | 0.0 | 0.0 | 0.2 | 0.0 | 0.0 | 0.2 | 0.0 | 0.0 | 0.2 | 0.0 |
| L | 0.0 | 4.5 | -0.1 | 0.0 | 6.6 | -0.1 | 0.0 | 5.4 | -0.1 | 0.0 | 6.5 | -0.2 |
| W+ | 0.0 | -7.8 | 5.8 | 0.0 | -11.3 | 5.6 | 0.0 | -9.2 | 5.2 | 0.0 | -11.3 | 5.1 |
| W- | 0.0 | -7.8 | -6.1 | 0.0 | -11.3 | -5.7 | 0.0 | -9.2 | -5.3 | 0.0 | -11.3 | -5.1 |
| WR | 0.0 | -7.8 | 0.2 | 0.0 | -11.3 | 0.2 | 0.0 | -9.2 | 0.2 | 0.0 | -11.3 | 0.3 |
| WL | 0.0 | -7.8 | 0.2 | 0.0 | -11.3 | 0.2 | 0.0 | -9.2 | 0.2 | 0.0 | -11.3 | 0.3 |
| E+ | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 |
| E- | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 |

LOAD GROUP DESCRIPTION

D : DEAD LOAD
C : COLLATERAL LOAD
L : LIVE LOAD
W+ : WIND LOAD AS AN INWARD ACTING PRESSURE
W- : WIND LOAD AS AN OUTWARD ACTING SUCTION
WR : WIND FORCE FROM THE RIGHT
WL : WIND FORCE FROM THE LEFT
E+ : EARTHQUAKE FORCE ACTING INWARD
E- : EARTHQUAKE FORCE ACTING OUTWARD




LOAD GROUP REACTION TABLE

| COLUMN | LEFT COLUMN | RIGHT COLUMN | INTERIOR COLUMN 1 | INTERIOR COLUMN 2 | INTERIOR COLUMN 3 | | | | | | | | | | |
|------------|----------------|----------------|-------------------|-------------------|-------------------|-----|-----|-------|------|-----|------|------|-----|-------|------|
| BASE PLATE | 8.0X12.5X0.375 | 6.0X10.0X0.375 | 6.0X12.0X0.375 | 6.0X10.5X0.375 | 6.0X12.5X0.375 | | | | | | | | | | |
| ANC. BOLTS | (4)-3/4 | (4)-3/4 | (4)-5/8 | (4)-5/8 | (4)-5/8 | | | | | | | | | | |
| LOAD GROUP | HL | VL | LL | HR | VR | LR | HI | VI | LI | H2 | V2 | L2 | H3 | V3 | L3 |
| D | 0.0 | 0.1 | 0.0 | 0.0 | 0.8 | 0.0 | 0.0 | 1.7 | 0.0 | 0.0 | 1.6 | 0.0 | 0.0 | 1.9 | 0.0 |
| C | 0.0 | 0.1 | 0.0 | 0.0 | 0.1 | 0.0 | 0.0 | 0.2 | 0.0 | 0.0 | 0.2 | 0.0 | 0.0 | 0.2 | 0.0 |
| L | 0.0 | 2.6 | 0.0 | 0.0 | 2.6 | 0.0 | 6.5 | -0.2 | 0.0 | 5.4 | -0.1 | 0.0 | 6.6 | -0.1 | 0.0 |
| W+ | -0.1 | -5.1 | 2.4 | 0.1 | -5.1 | 0.0 | 0.0 | -11.3 | 5.1 | 0.0 | -9.2 | 5.2 | 0.0 | -11.3 | 5.6 |
| W- | -0.1 | -5.1 | -2.7 | 0.1 | -5.1 | 0.0 | 0.0 | -11.3 | -5.1 | 0.0 | -9.2 | -5.3 | 0.0 | -11.3 | -5.7 |
| WR | -0.1 | -5.1 | 0.0 | 0.1 | -5.1 | 0.0 | 0.0 | -11.3 | 0.3 | 0.0 | -9.2 | 0.2 | 0.0 | -11.3 | 0.2 |
| WL | -0.1 | -5.1 | 0.0 | 0.1 | -5.1 | 0.0 | 0.0 | -11.3 | 0.3 | 0.0 | -9.2 | 0.2 | 0.0 | -11.3 | 0.2 |
| E+ | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 |
| E- | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 |

LOAD GROUP DESCRIPTION

D : DEAD LOAD
C : COLLATERAL LOAD
L : LIVE LOAD
W+ : WIND LOAD AS AN INWARD ACTING PRESSURE
W- : WIND LOAD AS AN OUTWARD ACTING SUCTION
WR : WIND FORCE FROM THE RIGHT
WL : WIND FORCE FROM THE LEFT



LOAD GROUP REACTION TABLE

| COLUMN | INTERIOR COLUMN 4 | INTERIOR COLUMN 5 | INTERIOR COLUMN 6 | INTERIOR COLUMN 7 | | | | | | | | |
|------------|-------------------|-------------------|-------------------|-------------------|-------|------|-----|------|------|-----|-------|------|
| BASE PLATE | 6.0X12.5X0.375 | 6.0X12.5X0.375 | 6.0X10.5X0.375 | 6.0X12.5X0.375 | | | | | | | | |
| ANC. BOLTS | (4)-5/8 | (4)-5/8 | (4)-5/8 | (4)-5/8 | | | | | | | | |
| LOAD GROUP | H4 | V4 | L4 | H5 | V5 | L5 | H6 | V6 | L6 | H 7 | V 7 | L 7 |
| D | 0.0 | 1.5 | 0.0 | 0.0 | 1.9 | 0.0 | 0.0 | 1.6 | 0.0 | 0.0 | 1.7 | 0.0 |
| C | 0.0 | 0.1 | 0.0 | 0.0 | 0.2 | 0.0 | 0.0 | 0.2 | 0.0 | 0.0 | 0.2 | 0.0 |
| L | 0.0 | 4.5 | -0.1 | 0.0 | 6.6 | -0.1 | 0.0 | 5.4 | -0.1 | 0.0 | 6.5 | -0.2 |
| W+ | 0.0 | -7.8 | 5.8 | 0.0 | -11.3 | 5.6 | 0.0 | -9.2 | 5.2 | 0.0 | -11.3 | 5.1 |
| W- | 0.0 | -7.8 | -6.1 | 0.0 | -11.3 | -5.7 | 0.0 | -9.2 | -5.3 | 0.0 | -11.3 | -5.1 |
| WR | 0.0 | -7.8 | 0.2 | 0.0 | -11.3 | 0.2 | 0.0 | -9.2 | 0.2 | 0.0 | -11.3 | 0.3 |
| WL | 0.0 | -7.8 | 0.2 | 0.0 | -11.3 | 0.2 | 0.0 | -9.2 | 0.2 | 0.0 | -11.3 | 0.3 |
| E+ | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 |
| E- | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 |

LOAD GROUP DESCRIPTION

D : DEAD LOAD
C : COLLATERAL LOAD
L : LIVE LOAD
W+ : WIND LOAD AS AN INWARD ACTING PRESSURE
W- : WIND LOAD AS AN OUTWARD ACTING SUCTION
WR : WIND FORCE FROM THE RIGHT
WL : WIND FORCE FROM THE LEFT




LOAD GROUP REACTION TABLE

| COLUMN | LEFT COLUMN | RIGHT COLUMN | INTERIOR COLUMN 1 | INTERIOR COLUMN 2 | | | | | | | | |
|------------|----------------|----------------|-------------------|-------------------|------|-----|-----|------|------|-----|------|------|
| BASE PLATE | 6.0X10.0X0.375 | 6.0X10.0X0.375 | 6.0X8.0X0.375 | 6.0X8.0X0.375 | | | | | | | | |
| ANC. BOLTS | (4)-3/4 | (4)-3/4 | (4)-5/8 | (4)-5/8 | | | | | | | | |
| LOAD GROUP | HL | VL | LL | HR | VR | LR | HI | VI | LI | H2 | V2 | L2 |
| D | 0.0 | 0.4 | 0.0 | 0.0 | 0.4 | 0.0 | 0.0 | 0.6 | 0.0 | 0.0 | 0.6 | 0.0 |
| C | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.1 | 0.0 | 0.0 | 0.1 | 0.0 |
| L | 0.0 | 1.1 | 0.0 | 0.0 | 1.1 | 0.0 | 0.0 | 2.3 | 0.0 | 0.0 | 2.3 | 0.0 |
| W+ | 0.0 | -2.0 | 0.0 | 0.1 | -2.6 | 0.0 | 0.0 | -4.1 | 2.2 | 0.0 | -4.4 | 2.3 |
| W- | 0.0 | -2.0 | 0.0 | 0.1 | -2.6 | 0.0 | 0.0 | -4.1 | -2.4 | 0.0 | -4.4 | -2.5 |
| WR | 0.0 | -2.0 | 0.0 | 0.1 | -2.6 | 0.0 | 0.0 | -4.1 | 0.0 | 0.0 | -4.4 | 0.0 |
| WL | 0.0 | -2.0 | 0.0 | 0.1 | -2.6 | 0.0 | 0.0 | -4.1 | 0.0 | 0.0 | -4.4 | 0.0 |

LOAD GROUP DESCRIPTION

D : DEAD LOAD
C : COLLATERAL LOAD
L : LIVE LOAD
W+ : WIND LOAD AS AN INWARD ACTING PRESSURE
W- : WIND LOAD AS AN OUTWARD ACTING SUCTION
WR : WIND FORCE FROM THE RIGHT
WL : WIND FORCE FROM THE LEFT



LOAD GROUP REACTION TABLE

| COLUMN | LEFT COLUMN | RIGHT COLUMN | INTERIOR COLUMN 1 | INTERIOR COLUMN 2 | | | | | | | | |
|------------|----------------|----------------|-------------------|-------------------|-------|-----|-----|-------|-----|-----|-------|-----|
| BASE PLATE | 8.0X15.0X0.375 | 8.0X10.0X0.375 | 12.0X12.0X0.75 | 12.0X12.0X0.75 | | | | | | | | |
| ANC. BOLTS | (6)-3/4 | (4)-3/4 | (4)-3/4 | (4)-3/4 | | | | | | | | |
| LOAD GROUP | HL | VL | LNL | HR | VR | LNR | HI | VI | LNI | H2 | V2 | LN2 |
| DL | 2.3 | 5.0 | 0.0 | -2.3 | 5.1 | 0.0 | 0.0 | 5.5 | 0.0 | 0.0 | 5.5 | 0.0 |
| COLL | 0.3 | 0.6 | 0.0 | -0.3 | 0.6 | 0.0 | 0.0 | 0.7 | 0.0 | 0.0 | 0.7 | 0.0 |
| PLL1 | 4.3 | 12.3 | 0.0 | -4.3 | 2.8 | 0.0 | 0.0 | 14.8 | 0.0 | 0.0 | -6.5 | 0.0 |
| PLL2 | -1.0 | -1.0 | 0.0 | 1.0 | -1.0 | 0.0 | 0.0 | 8.7 | 0.0 | 0.0 | 8.7 | 0.0 |
| PLL3 | 4.3 | 2.8 | 0.0 | -4.3 | 12.3 | 0.0 | 0.0 | -6.5 | 0.0 | 0.0 | 14.9 | 0.0 |
| LL | 7.6 | 14.1 | 0.0 | -7.6 | 14.0 | 0.0 | 0.0 | 17.0 | 0.0 | 0.0 | 17.1 | 0.0 |
| RBDWEQ | 0.0 | 0.9 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 |
| EQ | -0.6 | -0.3 | 0.0 | -0.6 | 0.3 | 0.0 | 0.0 | 0.6 | 0.0 | 0.0 | -0.6 | 0.0 |
| RBUPEQ | 0.0 | -0.9 | -1.3 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 | 0.0 |
| WL1 | -15.8 | -25.2 | 0.0 | 4.8 | -16.4 | 0.0 | 0.0 | -23.9 | 0.0 | 0.0 | -17.1 | 0.0 |
| WL2 | -13.0 | -14.5 | 0.0 | 2.0 | -5.7 | 0.0 | | | | | | |